

14-004 SIDE STEP BRACKETS INSTALLATION INSTRUCTIONS

WILL FIT CLUB CAR® PRECEDENT®/
TEMPO®/ONWARD®



Brackets

HARDWARE INCLUDED

- (2) M10 U-Bolts 50mm x 135mm
- (4) M10 Flat Washer
- (4) M10 Lock Nuts

TOOLS NEEDED

- 17mm Socket
- 17mm Wrench
- 13mm Socket

WARNING: WE RECOMMEND PROFESSIONAL INSTALLATION. IF YOU CHOOSE TO NOT HAVE THIS PRODUCT INSTALLED BY A PROFESSIONAL, WE HIGHLY RECOMMEND THAT YOU EXERCISE CAUTION, CARE, AND PATIENCE WHEN INSTALLING THIS PRODUCT.

STEP 1:



13mm Wrench

Remove and retain factory nuts under frame using 13mm socket as shown.



STEP 2:

Place mounting bracket to frame with angled section towards the front. Hand tighten retained hardware.

DO NOT tighten completely until end of installation. The U-bolt still needs to be inserted at front of bracket.

