



Enclosure Installation Instructions

for ICON® i40X
and i60LX

Part numbers starting with
21-ICX44FT0 and **21-ICX66FT0**



ITEMS INCLUDED

The following are zipped together in the box and can be separated for installation:

- Strut Covers (Driver & Passenger Side)
- Enclosure Panels with Valence (Driver Side, Passenger Side, & Rear)

STEP 1

Remove windshield as shown and retain all pieces
and hardware.



STEP 2

Wrap the front strut cover around the front struts and attach with the small zipper located on the inside.

NOTE: The windshield clip cut-outs are located on the top of the strut covers.



STEP 3

Feed piping of each panel down the outer track of the top. Repeat on all three sides. Then, connect all sides and strut covers by pulling snug and zipping together.

Note: Make sure excess panel is held even with track to avoid binding when sliding into track.



STEP 4

Reinstall your windshield by marking the OEM mounting holes on top of the front strut cover with an "X." Cut a very small "X" with a razor knife enough to insert windshield hardware through, being sure not to cut through the zipper on the back side (OK to cut through the fabric around the zipper). Reinstall windshield using retained hardware.



STEP 5

Now that all pieces are on the cart, ensure the enclosure is properly aligned to match cart body lines. When satisfied, attach all hook and loop straps.



INSTALLATION COMPLETE