



Part #: 03-155

Overhead Canvas Storage

Installation Instructions

Tops Sold Separately

ITEMS INCLUDED

- Storage System
- Dacromet Hardware Pack
 - 4 - M8 x 25mm Carriage Head Bolts
 - 4 - M8 Flat Washers
 - 4 - M8 Lock Washers
 - 4 - M8 Nuts

TOOLS NEEDED

- 13mm Socket
- Tape Measure



This storage system is specifically designed to fit the Versa Top Triple Track accessory rail. It will also fit the Red Dot Top Sail and 54" Club Car Precedent/Tempo & Yamaha Drive G29/Drive2 OEM tops which is shown on page 2.

If installing to Versa Triple Track Top (not installed)



13mm Socket or Wrench

A) If top is not yet installed or you are installing on a E-Z-GO TXT/RXV, slide two Carriage head bolts down each side of the Triple Track rail about 1 foot back from the front as shown.

B) Install top to struts using instructions from strut mounting kit. Adjust bolts to desired position, then secure Storage System to track using the supplied nut, lock washer, & flat washer.



If installing to Versa Triple Track Top (on cart)

 13mm Socket or Wrench

A) If Versa Triple Track Top is already installed you will need to temporarily remove front strut mounting bracket bolts from bracket. Slide the existing carriage head bolts down past the brackets and insert the new carriage bolts where the old ones were (bolts are identical). Reattach bracket to track.

B) Find your desired location for the Storage System and secure to carriage head bolts using supplied hardware.



If installing to Red Dot Top Sail Top on E-Z-GO TXT or RXV

 13mm Socket or Wrench

A) Place the supplied Carriage head bolts from the top, down into the front mounting brackets slots on the outer rails as shown.

B) Hand tighten hardware to ring grommets on outside of Storage System, align to your desired position and tighten hardware.



If installing to CC Precedent/Tempo or Yamaha DriveG29/Drive2 OEM tops or with Red Dot Top Sail.

 10mm Socket & Wrench

The Storage System will mount to the factory Club Car struts, remove the nuts from outside of the strut as shown. Fold each end around bottom of strut and secure to strut bolts as shown. 



 5mm Allen Head & 13mm Wrench

For Yamaha tops, remove the bolts of the front struts and fold each end of the Storage System on the inside of the struts and secure with strut bolts. 



INSTALLATION COMPLETE