



Metal Track Installation

(For Evolution D5 Top)

ITEMS INCLUDED

- 18 Self-Tapping Screws (+2 extra)
- 6 Metal Tracks:
 - A. Front Center of Car (33" Metal Track Bar)
 - B. Rear Center of Car (37.25" Metal Track Bar)
 - C. Driver & Passenger Side - Front (2 ea - 36.5" Metal Track Bar)
 - D. Driver & Passenger Side - Rear (2 ea - 30" Metal Track Bar)

TOOLS NEEDED

- Drill
- Phillips Head Drill Bit
- Permanent Marker
(To mark position on metal track for screw hole)
- Measuring Tape

STEP 1

Identify pre-drilled holes on top of car on all 4 sides as shown in Image A.

(They can be found on all 4 sides- see Image A)

If your cart has enclosure rails pre-installed skip to Sleeve installation.



Image A