



PART#04-038

INNER BASKET FOR YAMAHA® DRIVE®

INSTALLATION INSTRUCTIONS

TOOLS NEEDED:

Tape Measure
5/16" Drill Bit
Drill
13mm Socket
14mm Wrench
10mm Socket
10mm Wrench
Torpedo Level
(2) C-Clamps

INCLUDED:

(1) Basket
(2) Brackets
Hardware Pack
(2) 8mmx40mm Bolts
(4) 8mm Flat Washers
(2) 8mm Nylock Nuts
(4) 6mmx18mm Bolts
(8) 6mm Flat Washers
(4) 6mm Nylock Nuts



We recommend professional installation. If you choose to not have this product installed by a professional, we highly recommend that you exercise caution, care, and patience when installing this product as it involves drilling holes into your cart's body.

Install basket mounts to basket using 6mm bolts, washers and nuts supplied in hardware pack and secure.

1



2
Locate desired location on front strut that does not impede windshield mounts if applicable. Clamp basket mounts to location and mark holes to be drilled.



3
Drill hole through strut with 5/16" Drill Bit and secure mount basket with supplied 8mmx45mm bolts.



INSTALLATION COMPLETE

