



Enclosure Installation Instructions

for MadJax® Ascent™

Part numbers starting with
21-MJAS4FT0



ITEMS INCLUDED

- Strut Covers (Driver & Passenger Side)
- Enclosure Panels with Valance (Driver Side, Passenger Side, & Rear)
- Front Valance
- Rivet & Snap Hardware Pack

STEP 1

Remove windshield as shown and retain all pieces
and hardware.



STEP 2

Wrap the front strut covers around the front struts and attach with the small zipper located on the inside.

NOTE: The windshield clip cut-outs are located on the top of the strut covers.

NOTE: Do not attach the adhesive pieces yet. These will be attached in Step 5.



STEP 3

Feed piping of each panel and valance down the track of the top. Repeat on all four sides. Then, connect all sides and strut covers by pulling snug, zipping together, and attaching velcro.

Note: Make sure excess panel is held even with track to avoid binding when sliding into track.



STEP 4

Align the precut holes on the front strut covers with the OEM windshield mounting holes. Using a punch or razor knife, make a small hole to insert windshield hardware through, being sure not to cut through the zipper on the back side (OK to cut through the fabric around the zipper). Reinstall windshield using retained hardware.



STEP 5

Peel back the adhesive velcro on the bottom of the front strut covers and press firmly into place.



STEP 6

The included snaps and rivets can be installed to provide a more secure fit. After all hook and loop straps have been attached and tightened, use a riveter or rivet gun to attach snaps to front body trim where shown.



INSTALLATION COMPLETE