

TWO OPTIONS FOR WIRING INSTALLATION

First, identify the power cable for the MadJax® Thermaflex™ unit located at the bottom of the seat bottom.

OPTION 1

Utilize a female 2-pin Deutsch connector that plugs directly into the factory Thermaflex™ harness, so the female connector is wired directly into the vehicle's factory/aftermarket DC converter.



OPTION 2

(A) Splice the positive and negative wires from the 2-pin Deutsch connector and (B) add ring terminals/butt connectors that go directly to your factory/aftermarket DC converter.

