



E-Z-GO Express S4 Elite (2024+)



ITEMS INCLUDED

- 15 Self-Tapping Screws (3 are extra)
- 5 Metal Tracks:
 - A. Driver & Passenger – Rear (2 ea. 26" Metal Track Bar)
 - B. Driver & Passenger – Front (2 ea. 45¾" Metal Track Bar)
 - C. Rear Center of Car (35" Metal Track Bar)

TOOLS NEEDED

- Drill
- Phillips Head Drill Bit
- Permanent Marker (to mark position on metal track for screw hole)
- 9/16 wrench/socket
- Measuring Tape

TRACK INSTALLATION

STEP 1

Install rear driver side metal track first (note: all self-tapping screws should be screwed into the bottom lip of the roof frame) [Figure A].



Figure A