



Part # 26-200

Installation Instructions
Triple Track Top
Mounting Brackets

E-Z-GO RXV with Mach 3 Seat Kit



INCLUDED

- FRONT BRACKETS
- REAR BRACKETS
- HARDWARE PACK

TOOLS

- CORDLESS DRILL
- 7/16" DRILL BIT
- 5/16" DRILL BIT
- 17MM SOCKET
- 17MM WRENCH
- 13MM SOCKET
- 13MM WRENCH
- 10MM SOCKET
- C-CLAMPS

REAR
BRACKETS



FRONT
BRACKETS



CANDY CANE
STRUTS
(01-085 SOLD
SEPARATELY)

STEP 1


To begin, remove factory canopy and rear struts.
Retain all hardware.



STEP 2


(A) Attach front brackets to front struts using retained hardware from Step 1.

(B) A second hole will need to be drilled in strut. Using a 7/16" bit, drill through strut and attach using same length hardware retained from Step 1.



STEP 3

Clamp candy cane struts to seat back support bare of the G150 seat kit as shown. DO NOT drill holes for bolts until Step 8, to ensure desired height of top.



STEP 4

Using rear bracket as a template square end of strut and bracket. Using a marking pen, mark hole location. Drill marked hole with a 5/16" bit.




STEP 5

(A) Attach rear brackets to candy cane struts using 6mm x 40mm carriage bolts as shown. Be sure to mount bracket using the smaller diameter holes.

(B) Carriage bolt will secure to strut once hardware is tightened.

(A)



(B)



STEP 6


Connect the strut brackets to the top extrusion using 8mm carriage bolts. Hand tighten hardware first. Once all bolts are in place, tighten all bolts securely.

Rear Bracket



STEP 7

Connect the front strut brackets to the top extrusion by hand tightening all hardware first.



STEP 8

(A) Now that the top is in place, find desired height of rear. Using a 7/16" bit, drill through candy cane struts using holes in seat support bar as a guide.

(B) Using 10mm x 70mm bolts attach struts to seat back support bar as shown.



HARDWARE PACK

Dacromet Coated

4 - 6mm x 40mm Carriage Bolts
8 - 8mm x 25mm Carriage Bolts
4 - 10mm x 70mm Hex Head Bolts
4 - 6mm Lock Washers
4 - 6mm Flat Washers
4 - 6mm Nuts
8 - 8mm Lock Washers
8 - 8mm Flat Washers
8 - 8mm Nuts
8 - 10mm Flat Washers
4 - 10mm Nylock Nuts

